












Dell 34 Plus USB-C-monitor
S3425DW
























2












Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/S3425DW